

gamma-tocopherol by HPLC µg/g

Fraction I <sup>a)</sup> Tr

Fraction II <sup>b)</sup> Tr

delta-tocopherol by HPLC µg/g

Fraction I <sup>a)</sup> N.D.

Fraction II <sup>b)</sup> N.D.

all-trans retinol by HPLC (IU)

Fraction I <sup>a)</sup> 395,57

Fraction II <sup>b)</sup> 440,47

cholecalciferol by HPLC (IU)

Fraction I <sup>a)</sup> N.D.

Fraction II <sup>b)</sup> N.D.

---

Data from Professor Robert Ackman's laboratory, Canadian Institute of Fisheries Technology,

Halifax, Nova Scotia.

Data expressed per gram of krill oil.

<sup>a)</sup> : Extraction made with a sample-acetone ratio of 1:6 (w/v), incubated 2h at 4°C.

<sup>b)</sup> : Extraction made with a sample-ethyl acetate ratio of 1:2 (w/v), incubated 30 min at 4°C, following a first extraction with acetone.

TR = trace

N.D. = not detected

Conversion : Vitamin            alpha-tocopherol            mg/g oil x 1,36 = International Unit

                                 All-trans retinol            µg/g ÷ 0,3 = International Unit

**TABLE 17. ASTAXANTHIN AND CANTHAXANTHIN CONTENT OF KRILL OIL  
(*E. pacifica*)**

090314-070520-9170550  
a  
ant

---

Asthaxantin (µg/g oil)

Fraction I <sup>a)</sup>	93,1
Fraction II <sup>b)</sup>	121,7

Canthaxanthin (µg/g oil)

Fraction I <sup>a)</sup>	270,4
Fraction II <sup>b)</sup>	733,0

---

Data from Professor Robert Ackman's laboratory, Canadian Institute of Fisheries Technology,  
Halifax, Nova Scotia.

<sup>a)</sup> : Extraction made with a sample-acetone ratio of 1:6 (w/v), incubated 2h at 4°C.

<sup>b)</sup> : Extraction made with a sample-ethyl acetate ratio of 1:2 (w/v), incubated 30 min at 4°C, following a first extraction with acetone.

**TABLE 18. OPTIMAL CONDITIONS FOR LIPID EXTRACTION OF AQUATIC ANIMAL TISSUES (suggested procedure)**

---

<u>STEP</u>	<u>CONDITIONS</u>
Grinding (if particles > 5mm)	4°C
Lipid extraction	sample-acetone ratio of 1:6 (w/v) 2h (including swirling 20 min) 4°C
Filtration	organic solvent resistant filter

09830146-071604  
105240-971604  
A  
Cont

	under reduced pressure
Washing	sample-acetone ratio of 1:2 (w/v) pure and cold acetone
Filtration	organic solvent resistant filter under reduced pressure
Evaporation	under reduced pressure
Oil-water separation	4°C
Lipid extraction	<u>sample: ethyl acetate</u> ratio of 1:2 (w/v) <sup>a)</sup> pure <u>ethyl acetate</u> 30 min 4°C <sup>b)</sup>
Filtration	organic solvent resistant filter under reduced pressure
Evaporation	under reduced pressure

---

a): Ethanol can be replaced by isopropanol, *t*-butanol or ethyl acetate.

b): 25 °C when using *t*-butanol.

**TABLE 19: PROTEOLYTIC ACTIVITY OF KRILL RESIDU USING LACTOSERUM AS THE SUBSTRATE, AT 37 °C, PH 7.0 FOR A RATIO ENZYME:SUBSTRATE OF 1:43**

---

Time (min)	Amino acids released (µmoles)	Enzymatic rate (µmoles/min)	Specific activity	enzymatic
---------------	----------------------------------	--------------------------------	----------------------	-----------

0903046-02501  
 105220-94T0E860  
 a-  
 Cont.